



ONDERDELENLIJST**EHB 16/2.4 S RL**

10.014.02

Positie	Artikel	Omschrijving	Aantal
1	40.390	Aansl.snoer H07RN-F 2x1.5 3m	1
2	10.202.00	Omschakelaar R/L	1
3	10.515	Ontstoringcondensator	1
4	10.720.02	Handgreepkappen EHR 15 SB	1
5	10.519	Kabeltule 23/2	1
6	10.720.04	Schakelaar EHR 15 SB	1
7	10.720.10	Plaatschroef HC4,2x22 DIN 7981	3
8	10.520	Trekontlastingsklem	1
9	10.521	Plaatschroef hc4,2x16 din 7981	2
10	10.568	Plaatschroef HC4,8x45 DIN 7981	4
11	10.202.01	Anker Compl. EHB 16/2.4 S R/L	1
12	10.720.11	O-ring 22x0,5	1
13	10.512	Lager 608 2RSH - C3	1
14	10.720.06	Koolborstel houderset	1
15	10.699.02	Koolborstelset 6,3x10x18	1
16	10.202.02	Zelft. schroef ZM4x12	4
17	10.201.38	Veerring B4	4
18	10.720.01	Motorhuis EHR 15 SB	1
19	10.197.35	Schroef C 3,9x60	2
20	10.588	Luchtgeleiding 20/2.3-20/2.1	1
21	10.530	Borgring 28/1,2 DIN 472	1
22	10.525	Lager 6001/2RSH-C3	2
23	10.529	Borgring 11/1	1
24	10.202.03	Aansluitdraad kort	1
26	10.720.15	Pakking EHR 16/2.4 S	1
27	08.002.08	Plaatschroef HC4,8X50 DIN7981	4
28	10.202.05	Veldwikkeling EHB 16/2.4 S R/L	1
29	10.202.06	Tandwielhuis EHB 16/2.4 S R/L	1
30	10.553	Schakelpal compleet	1
31	10.202.07	Schakelgaffel EHB 16/2.4 S	1
32	10.202.08	Hoofdass EHB 16/2.4 S R/L	1
33	10.210.49	Lager 6202 2RS	1
34	10.202.09	Passchijf 12/18x0,2	1
35	10.202.10	Hoofdastandwiel EHB 16/2.4 S	1
36	10.512	Lager 608 2RSH - C3	1
37	10.527	Naaldlager HK 0810	1
38	10.609	Tandwielblok 20/2.3 - 20/2.1	1
39	10.608	As v.tandwielblok 13 Z	1
40	10.642	Passchijf 5x5x28mm DIN 8856	1
41	10.202.11	Tussenastandwiel EHB 16/2.4 S	1
42	10.605	As + tandwielen 20/2.3-20/2.1	1
43	10.202.12	Tussenlagerschild EHB 16/2.4 S	1
44	10.381.40	Centstift tuss.lagersch. 4x12	1
45	10.525	Lager 6001/2RSH-C3	1
46	10.202.14	Aansluitdraad omschakelaar	1
47	10.805.67	Handgreep klem	1
48	10.202.13	Pasring tbv zijhandgreep	4